





soundperformancelab.com



Manual



AUTO DYNAMIC
DE-ESSER

Model 9629

Dual-channel De-Esser

Version 4.0 – 5/2000

R&D: Wolfgang Neumann

Written by Hermann Gier & Paul White

The information in this document has been carefully verified and is assumed to be correct. However Sound Performance Laboratory (SPL) reserves the right to modify the product described in this manual at any time. Changes without notice. This document is the property of SPL and may not be copied or reproduced in any manner, in part or full without the authorization of SPL.

Limitations of Liability:

In no event will SPL be liable for any damages, including loss of data, lost profits, cost of cover or other special, incidental, consequential or indirect damages arising from the use of the unit, however caused and on any theory of liability. This limitation will apply even if SPL or an authorized dealer has been advised of the possibility of such damage.

Sound Performance Lab

P.O. Box 12 27

D- 41368 Niederkrüchten, Germany

Tel +49-2163-98340

Fax +49-2163-983420

E-Mail: info@soundperformancelab.com

www.soundperformancelab.com



© 2000 SPL electronics GmbH. All rights reserved. Subject to change without notice.

Foreword	3
Thanks	3
Introduction	4
Installation & Security Advices	4
Connections	5
Control Elements	
S-Reduction	6
Auto Threshold	6
Male/Female	7
Active	7
Power Supply	7
Specifications	8
Warranty	9
Notes	10

Foreword

Dear customer,

congratulations on purchasing the SPL Auto Dynamic De-Esser. You have decided to use a high performance tool which sets you in the position to have faster success and a better sound quality in your music productions.

As a typical SPL unit the Auto Dynamic De-Esser combines exemplary specifications and high manufacturing standard with excellent sound quality to provide you a precious component for studio and P.A. purposes. Please read this manual carefully to ensure you have all the information you need to use the Auto Dynamic De-Esser.

We wish you every success with the Auto Dynamic De-Esser.

Your Sound Performance Lab Team

Thanks

I would like to start with my thanks to all our staff who created what is to be described here. The importance of their exceptional qualification and talents can't be overestimated. But the biggest thanks I owe their unbelievable engagement, creativity and productivity in realizing our projects.

Our products are often tested and compared in many publications and by our customers themselves and constantly valued with best results.

I would like to pass on this broad appreciation to those, who deserve it – my excellent colleagues.

Hermann Gier

Introduction

The Auto-Dynamic De-Esser is a highly specialized audio tool. It is used to reduce S-frequency of speakers and singers. It should perform without disturbing natural character and timbre of the voice. This is not an easy task. SPL has developed a new circuit design that combines ease of use with natural sounding and effective performance.

How do traditional De-Essers work?

Traditional De-Essers use compressor-technology. The control elements are a threshold control and a frequency control. The threshold sets the level at which de-essing starts and the frequency control sets the center frequency of a frequency band that is usually up to 3-4 kHz wide. Any S-frequency within that band causes the compressor to compress the entire frequency band. As a result the voice speaks through the noise or lisps.

How does SPL's Auto Dynamic De-Esser work?

The Auto Dynamic De-Esser utilizes a new circuit design that "scans" the frequency spectrum and automatically hones in on S-frequencies. Only these narrow-band frequencies are processed and adjacent frequencies are left untouched. The Auto Dynamic De-Esser reduces S-frequencies by feeding a phase inversed signal of the detected narrow band S-frequency back into the signal path. The S-frequency is cancelled out. Therefore the quality of De-Essing is significantly improved – the result is neutrality to the sound and an unobtrusive but very effective mode of operation. There are almost no negative side effects on the timbre and character of the voice, even while using a high intensity of S-Reduction.

Installation & Security Advices

The housing of the Auto Dynamic DeEsser has the standard 19"-EIA format and occupies 1U (44.45 mm) in your rack. When installing the unit in a 19"-rack, the rear side of the unit needs some support, especially in a touring case.



The Auto Dynamic DeEsser should not be installed directly above or below power amplifiers or near units which produce strong magnetic fields or extreme heat.

Check that the voltage details quoted on the back panel are the same as your local mains electricity supply. Use a minus (-) screwdriver to set the voltage selector to the appropriate value.


Never cover up the ventilation slots on the top of the unit. If, during operation, the sound is interrupted or indicators no longer illuminate, or if abnormal odor or smoke is detected, or if liquids are spilled on the unit, immediately disconnect the power cord plug and contact your dealer.

Only clean the Auto Dynamic DeEsser with a soft, lint-free cloth.

Switch off power of all units to be connected before you connect the Auto Dynamic De-Esser.

The Auto Dynamic De-Esser is fitted with both XLR-connectors and TRS stereo jacks for balanced operation, though the jacks may be used with unbalanced connections simply by plugging in mono jack-plugs. The level difference that normally occurs when a balanced input or output is used unbalanced is automatically compensated for.

Should the need arise to use the XLR connectors in an unbalanced system, pin 3 of the XLRs should be grounded. Inserting a mono jack also unbalances the XLRs.



Both output stages operate in parallel, so it is possible to connect two different destination units simultaneously, for example to record to two different media at the same time or split the output between a mixer and effects processor. However, only one type of input (jack or XLR) should be connected at a time – the Auto Dynamic De-Esser is not intended to be used as a mixer!


To ensure optimal signal quality, SPL has developed a new hybrid-component balanced input/output stage using all laser-trimmed resistors with a tolerance of 0.01%. This approach has resulted in an exceptionally high CCMR (common mode rejection): 100dB at 1kHz and 80dB at 10kHz. As a precaution, before connecting the Auto Dynamic De-Esser switch off power of the unit and of all units to be connected.

Rear panel


Balanced XLR and TRS stereo jack I/Os (+6 dB)

Voltage selector: 230 V/50 Hz or 115 V/60 Hz

GND Lift switch, CSA/UL approved 3-pole power plug



Control Elements



1

S-Reduction

S-Reduction controls the intensity of the de-essing effect. The LED-display shows the gain reduction of S-frequencies in a range between 0dB to -20dB in 2dB steps.

S-REDUCTION adjustments between 3 and 7 have proven to create best results in practical applications.

2

Auto-Threshold

AUTO-THRESHOLD activates a new function that automatically readjusts the threshold when the input gain varies due to varying distances of the speaker to the microphone. The de-essing remains on a constant level when Auto Threshold is activated (status-LED illuminated).

Especially with untrained speakers or in live applications the distance to the microphone sometimes varies dramatically. De-essers operating with common compressor technology change their de-essing intensity with varying input levels. As a de-esser should be used right after the microphone preamplifier and in front of a compressor/limiter, common de-essers produce negative side effects on the vocals such as speaking through the nose or lisping.

The Auto Threshold function gets rid of all these problems. No matter how much the input level varies, the de-essing is proportionally the same and a following compressor/limiter works better and more efficient.

The Male/Female-switch lets you select two different operation modes: The female mode is chosen when the switch is pressed and the status-LED illuminates. The automatic S-frequency recognition is set to the characteristics of female voices. The opposite position of the button switches to the male mode. The S-frequency recognition is then set to the characteristics of male voices. However, it may sometimes be necessary to use the MALE mode and female vocals and vice versa. The selection of this switch is largely depending on the character of the S-frequency.

The center frequency of the bandwidth where the Auto Dynamic De-Esser looks for S-frequencies is located at 6 kHz for male voices and around 7 kHz for female voices.

ACTIVE switches each channel in and out of processing. In order to minimize switching noise and transients the circuitry is switched in and out after the balancing stages.

The POWER switch activates the relay-hard-bypass circuitry, which is also activated when a power failure occurs on the primary or secondary side of the power supply.

3

Male/Female

4

Active

Power Supply

Special care has gone into the design of the power supply of the Auto Dynamic De-Esser because the power supply is the heart of any electronic system, and the better it is, the better the whole system works. In an audio system, this translates into better sound quality, lower noise and lower distortion. The power supply is based around a specifically produced 15VA toroidal transformer and is designed to minimize induced hum and noise due to the lack of an air-gap.

The primary voltage may be selected between 230 V/50 Hz and 115V/60Hz by means of a recessed slide switch on the rear panel. A rear-panel ground-lift switch is fitted for use where ground loops are causing hum problems. When the GND Lift switch is pressed, the circuit ground is isolated from the chassis ground.

The detachable power cord is a standard 3-wire type fitted with an IEC mains connector; the transformer, power cord and mains connector have VDE, UL and CSA approvals. The fuse has a value of 200mA/230V and 400 mA/115 V for the primary voltage.

On the secondary side of the power supply, an RC combination is used to filter out noise and hum voltages. Both half-waves are smoothed with 2 x 1000 µF capacitors in the positive and 2 x 1000 µF capacitors in the negative voltage supply path, and both lines use precision voltage regulators for optimum stability. Deviations of only a few millivolts can impair audio quality, introducing artifacts such as loss of stereo imaging or a diffuse sound character.

Particular care has gone into the circuit layout and component choice to minimize crosstalk between the audio circuitry and control voltages.

Specifications

Input & Output

Instrumentation amplifier, electronically balanced (differential), transformerless

Nominal input level..... +6 dB

Input impedance = 22 kOhms

Output impedance < 600 Ohms

Max. input level +24 dBu

Max. output level +22,4 dBu

Minimum load ohms 600 Ohms

Hard Bypass Relay / Power Fail Safety

Measurements

Frequency response 20 Hz - 50 kHz
(50 kHz = -3 dB)

CCMR (common mode rejection) -80 dBu @1kHz

THD & N 0,002% @ 1kHz

S/N CCIR 468-3 -93 dBu

S/N A-weighted -106 dBu

Power Supply

Torroidal transformer 15 VA

Fuse 200 mA

Ground-Lift switch yes

Voltage selector yes

Dimensions

Housing Standard EIA 19"/1U
... 482 x 44 x 237 mm

Weight..... 3,4 kg

Note: 0 dBu = 0.775 V. Subject to change without notice.

SPL electronics GmbH (hereafter called SPL) products are warranted only in the country where purchased, through the authorized SPL distributor in that country, against defects in material or workmanship. The specific period of this limited warranty shall be that which is described to the original retail purchaser by the authorized SPL dealer or distributor at the time of purchase.

SPL does not, however, warrant its products against any and all defects:

- 1) arising out of materials or workmanship not provided or furnished by SPL, or
- 2) resulting from abnormal use of the product or use in violation of instructions, or
- 3) in products repaired or serviced by other than authorized SPL repair facilities, or
- 4) in products with removed or defaced serial numbers, or
- 5) in components or parts or products expressly warranted by another manufacturer.

SPL agrees, through the applicable authorized distributor, to repair or replace defects covered by this limited warranty with parts or products of original or improved design, at its option in each respect, if the defective product is shipped prior to the end of the warranty period to the designated authorized SPL warranty repair facility in the country where purchased, or to the SPL factory in Germany, in the original packaging or a replacement supplied by SPL, with all transportation costs and full insurance paid each way by the purchaser or owner.

All remedies and the measure of damages are limited to the above services. It is possible that economic loss or injury to person or property may result from the failure of the product; however, even if SPL has been advised of this possibility, this limited warranty does not cover any such consequential or incidental damages. Some states or countries do not allow the limitations or exclusion of incidental or consequential damages, so the above limitation may not apply to you.

Any and all warranties, expressed or implied, arising by law, course of dealing, course of performance, usage of trade, or otherwise, including but not limited to implied warranties of merchantability and fitness for particular, are limited to a period of 1 (one) year from either the date of manufacture. Some states or countries do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state, country to country.

SPL electronics GmbH, D-41372 Niederkrüchten, Germany